

# **Sensor Holders**

Stainless Steel, for Toggle Clamp with Horizontal Base, with / without Sensor

# SPECIFICATION

#### Types

- Type V: For toggle clamp with vertical tension lever
- Type  ${\bf H}:$  For toggle clamp with horizontal tension lever

#### Identification no.

- No. 1: With proximity sensor
- No. 2: Without proximity sensor

Retaining bracket / Retaining plate

# Stainless steel AISI 304

Setting nuts

Stainless steel AISI 304

#### Socket cap screws / Washers / Nuts Stainless steel

#### Proximity sensor at identification no. 1

- Housing, stainless steel AISI 304
- Inductive, 3-pole, PNP contact
- Thread M8 x 1
- Operating temperature -25 °C to +80 °C

#### INFORMATION

Sensor holders GN 801.3 are designed as accessories for GN 810 (see page 1562) and GN 820 (see page 1576) series toggle clamps and enable contactless monitoring of the clamping positions using an inductive sensor.

When the clamping lever is in clamping position, the sensor electronics provide a high signal, e.g. to a machine control unit, and additionally indicate this switch status with an LED on the sensor.

Operating errors can thus be reliably detected and process reliability increased.

The sensor holder can be retrofitted to toggle clamps and mounted on the right or left, depending on the installation situation of the toggle clamp. All parts are supplied unmounted as a set. The proximity sensor is not included in the scope of delivery of identification no. 2.

V eqvT

+





#### ACCESSORY

• GN 330 Cables with Connector Coupling (3-pole, 2 or 5 meters long) (see page 1448)

#### **TECHNICAL INFORMATION**

- Assembly Instruction (see page )
- Electrical properties of the inductive proximity sensor (see page )
- General Information for Toggle Clamps (see page 1560)
- Stainless Steel Characteristics (see page A26)

Alternative mounting side



### STAINLESS STEEL

≈ h≈	Length I ≈	For toggle clamp GN 810,	52	Description	Size	b≈	h≈	Length I ≈	For toggle clamp	52
		GN 810.3						8	GN 820, GN 820.3	55
.9 40	52	130	67	GN 801.3-130-H-1	130	45.4	41	48	130	68
.9 40	52	130	52	GN 801.3-130-H-2	130	45.4	41	48	130	53
.1 44	54	230	76	GN 801.3-230-H-1	230	52.1	45	50	230	77
.1 44	54	230	61	GN 801.3-230-H-2	230	52.1	45	50	230	62
).	.9 40 3.1 44	.9 40 52   3.1 44 54	.9     40     52     130       .1     44     54     230	.9     40     52     130     52       3.1     44     54     230     76	.9     40     52     130     52     GN 801.3-130-H-2       3.1     44     54     230     76     GN 801.3-230-H-1	.9     40     52     130     52     GN 801.3-130-H-2     130       8.1     44     54     230     76     GN 801.3-230-H-1     230	9     40     52     130     52     GN 801.3-130-H-2     130     45.4       8.1     44     54     230     76     GN 801.3-230-H-1     230     52.1	.9     40     52     130     52     GN 801.3-130-H-2     130     45.4     41       8.1     44     54     230     76     GN 801.3-230-H-1     230     52.1     45	1.9 40 52 130 52 GN 801.3-130-H-2 130 45.4 41 48   3.1 44 54 230 76 GN 801.3-230-H-1 230 52.1 45 50	.9   40   52   130   52   GN 801.3-130-H-2   130   45.4   41   48   130     .1   44   54   230   76   GN 801.3-230-H-1   230   52.1   45   50   230


STAINLESS STEEL GN 801 3-H

-2

GN 801.3-V




# Assembly Instruction



Sensor holders can be mounted on the left or right of the toggle clamp. To do this, the setting nuts must be tightened on the left or right of the retaining plate, to secure them against rotation and loss. This facilitates the further assembly of the sensor holder and the adjustment of the sensor. Subsequent changing of the mounting side is not intended.

The sensor is inserted into the bore in the retaining bracket according to the selected mounting side and the depth is adjusted and fastened using the nuts in such a way that the clamping lever reliably switches it in the clamping position.



EG

212